



RADIATION- TOLERANT CAMERA SYSTEM

# HD-RAD Pelicase



The HD-Rad Pelicase remote controller offers comprehensive and reliable control for your inspection and surveillance needs in a rapid setup package.

The camera controller is housed in a rugged, Pelican-style protective hard case and is mains-powered.

The unit includes all camera controls, a 22" HD monitor, text overlay, audio input, as well as an HD video recorder, which records video and audio onto a removable solid-state drive. Additionally, the unit supports the connection of a joystick controller and an external monitor, allowing for flexible and remote camera operation and viewing.



## FEATURES

- ✓ Housed in a rugged protective hard case
- ✓ Available controls:
  - Pan control (joystick)
  - Tilt control (joystick)
  - Zoom control (by joystick twist)
  - Iris, focus and light controls
- ✓ Inbuilt 22" HD monitor
- ✓ Text overlay
- ✓ Audio input
- ✓ HD video recorder
- ✓ Two removable memory cards
- ✓ Support for external monitor, remote control, and remote network access

## HD-RAD PELICASE

### SPECIFICATIONS AND PERFORMANCE

#### Materials/Dimensions/Weight:

- Housing material: HPX® High Performance Resin
- Overall dimensions:  
Closed: 202 (7.95") H x 538 (21.18") W x 464 (18.27") D  
Open: 554 (21.81") H x 538 (21.18") W x 512 (20.16") D
- Weight: 10.5 kg (23.1lb)

#### Electrical Connections:

- Mains supply: 100 to 240V AC, 50/60Hz, 100VA maximum
- Transient voltages on mains supply: Impulse withstand (overvoltage) category II of IEC 60364-4-443
- Pollution level: 2 (BS EN61010-1: 2001)
- Fuse: Anti-surge, high-breaking capacity, T3.15AH, 250V ceramic, 5 x 20 mm
- Auxiliary Video output 1: BNC, Composite video, Standard Definition
- Auxiliary Video output 2: HDMI, High-Definition
- Camera connector: 23-way multipole connector
- Remote keyboard connector: 9-pin D-sub
- Add-in network connection for ethernet

#### Environmental:


- Operating Temperature: 0° C to 40° C (32° F to 104° F)
- Storage Temperature: -20° C to 60° C (-4° F to 140° F)
- Humidity: 80% for temperatures up to 31° C decreasing linearly to 50% at 40° C
- Maximum Altitude: 2000 m

#### Video Recording:

- With PAL camera: approximately 12 hours w/ (2) 256 GB cards
- With NTSC camera: approximately 12 hours w/ (2) 256 GB cards  
2 x 256 GB 200 MB/s memory cards included

#### Additional Controller Features:

- Video out connectors: 1 HDMI and 1 HD-SDI BNC for HD output, 1 BNC for composite output
- Outstation Cable Length: 38 m (125') standard length to controller. Consult Mirion for alternate cable lengths
- Remote control connector: For use with a Pelco keyboard or any Pelco-D capable controller for wired remote camera control
- Ethernet connector for network connection: Allows for viewing and control over a network using a standard Internet browser
- Panel microphone: With ON/OFF/PUSH-TO-TALK switch to control audio input for recording
- Built-in sealed membrane keyboard: For use with Text Overlay function to add text in real time  
Text-Overlay functions include:
  - 30 lines of text
  - Time/date stamp
  - Measurement Markers
  - Reticule
  - Up/Down Timer



Copyright © 2025 Mirion Technologies, Inc. or its affiliates. All rights reserved. Mirion, the Mirion logo, and other trade names of Mirion products listed herein are registered trademarks or trademarks of Mirion Technologies, Inc. or its affiliates in the United States and other countries. Third party trademarks mentioned are the property of their respective owners.