




PROTK™

PN 25/PN 50™

B-10 Proportional Counters



Neutron flux detectors for the source range

DESCRIPTION

The B 10 proportional counters of type PN 25 and PN 50 are designed to measure the neutron flux outside the reactor core in the source range during reactor start-up. The detector signal consists of charge pulses that are generated in the active gas volume of the B 10 proportional counter by either the lithium nucleus or the alpha particle resulting from the B 10 (n, α) Li 7 reaction.

These detectors are available with a neutron sensitivity of 4.5 cps/nv for the PN 25 and from 5 to 15 cps/nv depending on the sensitive length for the PN 50. The typical thermal neutron flux range covered with these detectors is therefore approx. 0.1 nv to 3E+5 nv.

FEATURES

- ✓ Wide thermal neutron flux range
- ✓ Robust design, uniform sensitivity
- ✓ High temperature range (up to 200 °C)
- ✓ Available in various lengths with sensitivities up to 15 cps/nv
- ✓ Connectorized (HN connectors) or with integral mineral insulated cable (PN 50)
- ✓ Suitable for long-term operation in high radiation environment (w/o organic materials)
- ✓ Integral MI cable with PEEK layer for mechanical protection and electrical insulation (PN 50)
- ✓ Environmental and seismic qualification

PN 25/PN 50™ B-10 PROPORTIONAL COUNTERS


SPECIFICATIONS AND PERFORMANCE


Product Code	Sensitivity (cps/nv)	Operation Voltage (V DC)	Neutron Flux Range (nv)	Total/Sensitive Length (mm)	Diameter (mm)	Integral MI Cable/Impedance	Connector
PN 25	4.5	+700 ... +850	0.1 ... 2e+5	417/290	25	-	HN (female)
PN 50-2	5	+600 ... +900	0.1 ... 3e+5	379/180	50	max. 15 m/ 50 Ω	HN (female)
PN 50-4	10		0.1 ... 2e+5	559/360			
PN 50-6	15		0.1 ... 1e+5	739/540			

For specific applications and for receiving further technical data related to these and more detectors, please contact Mirion.

ENVIRONMENTAL DATA	
Operating temperature, humidity	Max. 200 °C, 100% r.H.
Ambient pressure (absolute)	0 ... 800 kPa
Gamma dose rate (Cs-137)	< 10 Gy/h
Neutron fluence, γ TID (detector and cable/connector)	2E+19 nvt > 200/> 4 MGy

MATERIALS	
Filling gas/pressure	Ar + CO ₂ /30 kPa
Detector housing and HV electrodes	Al, Al-Mg-alloy
Detector, Cable isolators	Al ₂ O ₃ SiO ₂ (PN 50)
Integral cable outer sheath, with isolation protection (optional)	Stainless steel, OD = 4 mm PEEK, OD = 4.7 mm

proTK™ SIGNAL PROCESSING UNITS AND MONITORS	
<p>Suitable signal processing unit for the proportional counters PN 25 and PN 50:</p> <p>DAK 260-i + NV 320</p> 	<p>Mirion can provide the complete neutron flux monitoring system for reactor start-up.</p> <p>In the source range the digital start-up signal processing unit DAK 260-i with the pulse pre-amplifier NV 320 is used with a PN 25 or PN 50 (other proportional counters are equally suitable).</p> <p>See also corresponding source range neutron flux monitor SRM 510.</p>



Copyright © 2024 Mirion Technologies, Inc. or its affiliates. All rights reserved. Mirion, the Mirion logo, and other trade names of Mirion products listed herein are registered trademarks or trademarks of Mirion Technologies, Inc. or its affiliates in the United States and other countries. Third party trademarks mentioned are the property of their respective owners.