



DOSIMETRY ACCESSORIES

SCC

Simulation Control Center



FEATURES

- Tablet or PC based Windows 10™ application and USB Dongle
- Wireless control and remote view of all connected devices
- Direct link or group control of multiple devices
- Configure device performance variables and settings
- Save preset dose and dose rate inputs
- Update device firmware
- Select up to 32 devices at once to configure and control
- Exchange training devices easily between instructors running SCC applications

DESCRIPTION

The Simulation Control Center (SCC) is a Windows 10™ application that uses a USB Dongle to wirelessly control all models supported in the Sim-Teq™ product line. This intuitive application allows the direct control of radiation levels reported by the simulated instrument, and provides a remote view of the measurements displayed on the controlled instrument. This application also is used to control the output of TWR “Live” Sources



RUN SEAMLESS TRAINING EXERCISES

- Wirelessly connect to any simulation device in the SIM-Teq™ product line.
- Configure and control all instrument specific features
- Observe the current dose and rate displayed on student's instrument
- Activate alarms and fault conditions
- Control groups of devices simultaneously
- Set the dose rate emitted from TWR "live" sources
- Swap between manual control and automatic response of devices to TWR sources

SIM-TEQ™ FEATURES:

- Easy to setup.
- Multiple models of survey instruments and dosimeters supported
- Wireless direct control of devices through SCC or automatic response of devices to TWR "live" sources.
- Free SCC software updates provided via Microsoft Windows Store.

PHYSICAL CHARACTERISTICS

- Full screen and intuitive user interface
- Manual Control Inputs:
 - Preset Pushbuttons - user configurable
 - Slide Bar
 - Numerical

OPERATING CHARACTERISTICS

- Supported Processors: x86, x64, ARM
- Supporting Devices: Windows 10™ tablets and computers (Requires SIM-Teq™ USB Dongle for communication to SIM-Teq™ training devices)
- Language: English
- Training Devices Supported: The SCC application supports all current SIM-Teq™ training devices. As new SCC application features and functions are added, as well as, new training instruments and accessories to the product line, the latest version of the SCC application is made available on the Windows Store for anyone to download.
- Manual Control Max Devices: 32
- Device Configuration Management
 - Default
 - Customize, Save and Store
- Designed specifically for wirelessly managing and controlling SIM-Teq™ training devices
- Directly control the display readings, faults or alarm indication of training device(s).